
## **Event Log / Error Log for AW-UE160**

Event Log and Error Log can be confirmed on WEB screen. (Setup → Maintenance → System log)

A maximum of 1000 event logs and a maximum of 100 error logs can be stored in the unit's internal memory.

When this maximum number has been exceeded, the old logs are overwritten successively by the new logs.

The logs are cleared when the unit's power is turned off.



## < Event Log >

Event Log	Note
No.	Up to 1000 events. The newest event log is No.1.
Date & Time	Date and Time that the event has occurred. Without time setting, bar is displayed.
Operation time	Hour Meter that the event has occurred.
Event code	Refer to the following table.
Description	Refer to the following table.

## < Error Log >

Error Log	Note
No.	Up to 100 errors. The newest event log is No.1.
Date & Time	Date and Time that the error has occurred.
Operation time	Hour Meter that the error has occurred.
Error code	Refer to the following table.
Error description	Refer to the following table.

## < Event Log table >

Event Code	Event Description	Note
W0001	<power> System start.</power>	Power was supplied and system started.
W0002	<power> Power on.</power>	"Power ON" .
W0003	<power> Standby.</power>	"Standby" button is pressed on WEB screen.
W0005	<power> POE+ (Hardware) is working.</power>	POE+ power supply was OK. (Hardware detection)
W0006	<power> POE+ (Software) is working.</power>	POE+ power supply was OK. (Software detection)
W1003	<maintenance> Succeeded OSD Menu</maintenance>	Initialization of OSD menu menu setting values (Maintenance ->
	initialization	Initialize) are successful.
W1004	<maintenance> Succeeded ALL Menu</maintenance>	Initialization of OSD menu, SCENE files 1 to 8 and USER files 1

	initialization	to 3.was successful.
W1005	<maintenance> Succeeded firmware update</maintenance>	Firmware update (Maintenance -> Product info) was successful.
W1006	<maintenance> Failed firmware update</maintenance>	Firmware update (Maintenance -> Product info) failed.
W1007	<maintenance> Succeeded OSD menu and</maintenance>	"Reset to the default (Except the network settings)" of WEB menu
VV 1007	WEB menu initialization	(Maintenance -> Default reset) was successful.
W1008	<maintenance> Reboot</maintenance>	"Reboot" of WEB menu (Maintenance -> Default reset) was
***1000	Waintenance Report	executed.
W1009	<maintenance> Succeeded configuration</maintenance>	Setting data upload (Maintenance -> Backup) was successful.
	data upload	County data apical (Maintonance > Eachap) was successful.
W1203	<pre><date&time> Date&amp;Time exchanged</date&time></pre>	Date and time has been set.
		PC synchronization / NTP sever connection / Manual setting Time synchronization succeeded
W1205	<ntp> NTP update succeeded</ntp>	The connection error with the NTP server.
W1206	<ntp> No response from the NTP server</ntp>	
W1210	<https> Self-signed Certificate Generated</https>	Generating the Self-signed Certificate has been completed.
W1211	<https> Self-signed Certificate Deleted</https>	Deleting the Self-signed Certificate has been completed.
W1212	<https> Certificate Signing Request</https>	Generating the Certificate Signing Request has been completed.
	Generated	
W1213	<hr/>	Installation of the CA Certificate has been completed.
W1214	<hr/>	Deleting the CA Certificate has been completed.
W1215	<hr/> HTTPS> Previous CRT key Applied	The previous CRT key has been applied.
W1216	<hr/> HTTPS> CRT key Generated	Generating the CRT key has been completed.
W1217	<genlock> Genlock succeeded</genlock>	After detecting the genlock signal, the external lock succeeded.
W1303	<login> Remote camera controller</login>	ROP connection and IP / account information
	connected [username] [IP address]	
W1311	<stream> Mjpeg ch1 Play [username] [IP</stream>	User information display who started mjpeg delivery
	address]	
W1312	<stream> Mjpeg ch2 Play [username] [IP</stream>	User information display who started mjpeg delivery
	address]	Hear information display who started miner delivery
W1313	<stream> Mjpeg ch3 Play [username] [IP</stream>	User information display who started mjpeg delivery
	address]	User information display who stopped mjpeg delivery
W1314	<stream> Mjpeg ch1 Stop [username] [IP</stream>	Oser information display who stopped hijpeg delivery
14/40/45	address]	User information display who stopped mjpeg delivery
W1315	<stream> Mjpeg ch2 Stop [username] [IP</stream>	Oser information display who stopped hijpeg delivery
14/4040	address]	User information display who stopped mipeg delivery
W1316	<pre><stream> Mjpeg ch3 Stop [username] [IP</stream></pre>	Osci information display who stopped hijpeg delivery
10/4047	address]	User information display who started H.264 delivery
W1317	<pre><stream> H.264 ch1 Play [username] [IP</stream></pre>	Cool information diopidy time stated thize t delivery
W1318	address]   <stream> H.264 ch2 Play [username] [IP</stream>	User information display who started H.264 delivery
VV 13 10	address]	, ,,
W1319	<pre>   address]    <stream> H.264 ch3 Play [username] [IP</stream></pre>	User information display who started H.264 delivery
**1019	address]	
W1321	<pre><stream> H.264 ch1 Stop [username] [IP</stream></pre>	User information display who stopped H.264 delivery
	address]	
W1322	<pre><stream> H.264 ch2 Stop [username] [IP</stream></pre>	User information display who stopped H.264 delivery
	address]	
W1323	<pre><stream> H.264 ch3 Stop [username] [IP</stream></pre>	User information display who stopped H.264 delivery
	address]	
W1325	<stream> H.265 ch1 Play [username] [IP</stream>	User information display who started H.265 delivery
	address]	

W1326	<stream> H.265 ch1 Stop [username] [IP address]</stream>	User information display who stopped H.265 delivery
W1327	<stream> Reached the number of connections limit [username] [IP address]</stream>	Maximum number of connections
W1328	<stream> Reached the processing limit</stream>	CPU load upper limit
W1329	<stream> reached the bandwidth limit</stream>	Bandwidth upper limit
W1331	<contorol> lock remote control [username] [IP address]</contorol>	Lockout start and IP/account information
W1332	<control> Unlock remote control [username] [IP address]</control>	Lockout release and IP/account information
W1341	<stream> H.265 ch2 Play [username] [IP address]</stream>	User information display who started H.265 delivery
W1342	<stream> H.265 ch2 Stop [username] [IP address]</stream>	User information display who started H.265 delivery
W1345	<stream> NDI Add Client. [number of Client]</stream>	High bandwidth NDI/NDI HX V2 Client additional information
W1346	<stream> NDI Decrease. [number of Client]</stream>	High bandwidth NDI/NDI HX V2 Client deletion information

< Error Log table >

Error Log		N 4 (5 4 )
Code	Event Description	Note (Factor)
0x00	Normal	No Error
0x03	Motor Driver Error (PAN)	PAN Motor drive error
0x03	Motor Driver Error (TILT)	TILT Motor drive error
0x04	Pan Sensor Error	Pan sensor Error(Servo)
0x05	Tilt Sensor Error	Tilt sensor Error(Servo)
0x21	System Error	System error
0x22	Spec Limit Over (Pan)	Limit error (PAN)
0x22	Spec Limit Over (Tilt)	Limit error (TILT)
0x25	Main Life-monitoring Error	BE CPU alive monitoring timeout
0x30	NET Life-monitoring Error	FPGA alive monitoring timeout
0x31	Fan1 error	Fan Error(Lens side)
0x32	Fan2 error	Fan Error(Rotaly table side)
0x33	High Temp	high temperature condition
0x36	Low Temp	Low temperature condition
0x40	Temp Sensor Error	Temperature sensor Error(Lens or Main)
0x41	Lens Initialize Error	Lens origin search failed(Lens)
0x42	PT. Initialize Error	Pan/Tilt origin search failed(Servo)
0x43	PoE++ Software auth. Timeout	PoE++ Timeout error
0x50	MR Level Error(PAN)	MR Level Error(PAN)
0x50	MR Level Error(TILT)	MR Level Error(TILT)
0x52	MR Offset Error(PAN)	MR Offset Error(PAN)
0x52	MR Offset Error(TILT)	MR Offset Error(TILT)
0x55	PT. Gear Error (PAN)	PT. Gear Error (PAN)
0x55	PT. Gear Error (TILT)	PT. Gear Error (TILT)
0x57	Gyro Error	Gyro Error
0x58	PT. Initialize Error (PAN)	Origin position search failed(PAN)
0x58	PT. Initialize Error (TILT)	Origin position search failed(TILT)
0x60	Update Firmware Error	Firmware error occurred during update
0x61	Update Hardware Error	Hardware error occurred during update

0x62	Update Error	Update Error
0x63	Update Fan Error	FAN motor lock error occurred during update