

# When Using Macintosh

## PC card slot driver for Macintosh PowerBook

This driver software is for referencing the content of a P2 card on a Macintosh PowerBook with a PC card slot. This driver software has been verified to work in the following Macintosh environment.

### ● **Compatible models**

PowerBook G4 Series

### ● **OS**

Mac OS X 10.4.11

Mac OS X 10.5.6

### <Note>


This driver software does not support Mac OS X 10.6/10.7.

### <Installing the PC card slot driver for Macintosh PowerBook>

- 1** Insert the supplied CD-ROM.
- 2** Double-click the **Macintosh** folder in the CD-ROM.
- 3** For Mac OS X 10.4  
Double-click the **Tiger** folder.  
  
For Mac OS X 10.5  
Double-click the **Leopard** folder.
- 4** Double-click **P2PCCard Install.pkg**.
- 5** The installation of the driver software will begin. Follow the instructions on the screen to complete the install.

### <Notes>

- Only the card slot driver will be installed.
- When removing the P2 card, drag the P2 card to the “Trash” and wait until the icon disappears.



The write-protect switch is not effective when the P2 card is inserted in the PC card slot.

Make sure you remove the P2 card from the PC card slot, set the switch, then re-insert the card, in order to effect the switch setting.