

## Restrictions when performing menu settings

Thank you for purchasing this Panasonic product.

This section describes the restrictions when performing menu settings.

### Interlocked menu items that change

When some menu item settings (left column of the table below) are changed, please note that there are other menu items (right column of the table below) that have their setting values interlocked with those settings, that are changed as well.

However, please also note that if a changed menu setting is restored to its original setting value, the interlocked menu settings' values will not be restored.

When [HIGH SENS.] is changed to [NORMAL] in the main menu → [PAINT] → [[S] CAMERA SETTING] → [SHOOTING MODE]	→	<ul style="list-style-type: none"> <li>• If [-6dB] is set in the main menu → [PAINT] → [LOW SETTING] → [[S] MASTER GAIN], it is changed to [-3dB].</li> <li>• If [-6dB] is set in the main menu → [PAINT] → [MID SETTING] → [[S] MASTER GAIN], it is changed to [-3dB].</li> <li>• If [-6dB] is set in the main menu → [PAINT] → [HIGH SETTING] → [[S] MASTER GAIN], it is changed to [-3dB].</li> </ul>
When [P2] or [P2&SD] is set in the main menu → [REC/PB] → [PROXY SETUP] → [REC MEDIA], and [LOOP] is changed to [NORMAL] in the main menu → [REC/PB] → [REC FUNCTION] → [RECORDING]	→	If [ONE FILE] is set in the main menu → [REC/PB] → [REC/PB SETUP] → [FILE SPLIT], it is changed to [SPLIT] ([SPLIT] returns it to the status of recording the proxy).
When a mode other than the 1080P mode ([1080-59.94P] or [1080-50P]) is changed to 1080P mode in the main menu → [SYSTEM] → [SYSTEM MODE] → [LINE&FREQ]	→	If [ON] is set in the main menu → [REC/PB] → [REC FUNCTION] → [PRE REC], it is changed to [OFF].
When [DVCPRO] or [DV] is set in the main menu → [SYSTEM] → [SYSTEM MODE] → [REC FORMAT], and SD mode ([480-59.94i] or [576-50i]) is changed to HD mode ([1080-59.94P], [1080-50P], [1080-59.94i], or [1080-50i]) in [LINE&FREQ]	→	If [9s] to [15s] is set in the main menu → [REC/PB] → [REC FUNCTION] → [PRE REC TIME], it is changed to [8s].
When SD mode ([480-59.94i] or [576-50i]) is set in the main menu → [SYSTEM] → [SYSTEM MODE] → [LINE&FREQ], and [DVCPRO] or [DV] is changed to [DVCPRO50] in [REC FORMAT]	→	If [9s] to [15s] is set in the main menu → [REC/PB] → [REC FUNCTION] → [PRE REC TIME], it is changed to [8s].
When items other than [DVCPRO HD] is changed to [DVCPRO HD] in the main menu → [SYSTEM] → [SYSTEM MODE] → [REC FORMAT]	→	If [24BIT] is set in the main menu → [SYSTEM] → [SYSTEM MODE] → [AUDIO SMPL RES], it is changed to [16BIT].
When an item other than [AVC-G50] or [AVC-G25] is changed to [AVC-G50] or [AVC-G25] in the main menu → [SYSTEM] → [SYSTEM MODE] → [REC FORMAT]	→	If [16BIT] is set in the main menu → [SYSTEM] → [SYSTEM MODE] → [AUDIO SMPL RES], it is changed to [24BIT].

### Restrictions when performing menu settings

The following content of restrictions when performing menu settings are provided in the Operating Instructions.

#### Chapter 3 Recording and Playback

##### “Proxy settings” (page 41)

###### Before revision

- Proxy data cannot be recorded in the following modes.
  - Loop recording
  - In SD mode (480/59.94i, 576/50i)



###### After revision

- Proxy data cannot be recorded in the following modes.
  - Loop recording
  - In SD mode (480/59.94i, 576/50i)
  - When [ONE FILE] is set in the main menu → [REC/PB] → [REC/PB SETUP] → [FILE SPLIT]

#### Chapter 7 Menu Operations

##### “Remark” in [RECORDING] (page 154)

###### Before revision

- Only [NORMAL] can be selected in the following cases:
  - When the main menu → [SYSTEM] → [SYSTEM MODE] → [REC SIGNAL] is set to other than [SDI]



###### After revision

- Only [NORMAL] can be selected in the following cases:
  - When the main menu → [SYSTEM] → [SYSTEM MODE] → [REC SIGNAL] is set to [SDI]
  - When the main menu → [SYSTEM] → [SYSTEM MODE] → [REC FORMAT] is set to [AVC-G50] or [AVC-G25]

#### **“Remark” in [FILE SPLIT] (page 155)**

---

##### **The following content is added**

- When [ONE FILE] is selected, proxy recording is not possible. Also, if [P2] or [P2&SD] is set in the main menu → [REC/PB] → [PROXY SETUP] → [REC MEDIA], [FILE SPLIT] is fixed to [SPLIT].

#### **“Remark” in [REC MEDIA] (page 156)**

---

##### **Before revision**

- In the following case, proxy data cannot be recorded even if [REC MEDIA] is set to [P2] or [P2&SD].
  - When the main menu → [REC/PB] → [REC FUNCTION] → [RECORDING] is set to other than [NORMAL]



##### **After revision**

- In the following cases, when [REC MEDIA] is [OFF], [P2] or [P2&SD] cannot be selected.
  - When the main menu → [REC/PB] → [REC FUNCTION] → [RECORDING] is set to other than [NORMAL]
  - When the main menu → [REC/PB] → [REC/PB SETUP] → [FILE SPLIT] is set to [ONE FILE]

#### **Items that do not work in [USER MENU SEL]**

---

Even if the following items that are displayed in the main menu → [USER MENU SEL] are selected, they are not displayed in [USER MENU]. They are currently non-functioning items.

- [VF] → [VF INDICATOR] → [UPLINK DEVCIE]
- [VF] → [MODE CHECK IND] → [UPLINK DEV. INFO]