

## 1. MENU OPERATION

### ■ カメラのダイレクト接続制御

- この機能は、AK-HC1500、AK-HC1800、AW-HE870のカメラで動作します。

回転台を介さず本機とカメラをシリアル接続し、カメラを制御することができます。

- 1 CTRL TYPEメニュー [36]を開き、F1ダイヤルを回して対象のカメラ番号 [CAM1] ~ [CAM5]を表示する
- 2 F2ダイヤルを回して [CAM\_Direct] を選択し、F2ダイヤルを押して確定する



カメラ番号CAM1 ~ CAM5に対して、カメラの制御をダイレクト制御 [CAM\_Direct] に設定することができます。

カメラ番号CAM1 ~ CAM5は、背面のTO PAN/TILT HEAD端子の [1] ~ [5]に対応しています。

- 付属のSetup SoftwareのCTRL TYPE項目でも設定することができます。

<NOTE>

- カメラ番号CAM6 ~ CAM100にダイレクト制御 [CAM\_Direct] を設定することはできません。

## 2. AW-HE870/AK-HC1500/AK-HC1800 接続時の PANEL/MENU 対応一覧

Control Panel				Operation
No	Section	Button	Item	
1	CAM CONTROL	AWB/ABB	ABB	OK
2			AWB	OK
3		BARS	BARS	OK
4		WHITE BAL	A	OK
5			B	OK
6			ATW	OK
7		R/B GAIN	R	OK
8			B	OK
9		R/B PED	R	OK
10			B	OK
11		PED	PED	OK
12		GAIN	GAIN	OK
13			AUTO	OK
14		DETAIL	DETAIL	OK
15	IRIS/ ZOOM/ FOCUD	IRIS	IRIS	OK
16			AUTO	OK
17		ZOOM	ZOOM	OK
18			SPEED	OK
19		FOCUS	FOCUS	OK
20			SPEED	OK
21			AUTO	—
22			OTAF	—
23	Indicator	Indicator	IRIS	OK
24			ZOOM	—
25			FOUCS	—
26	PAN/ TILT	PAT/ TILT	PAN/TILT	—
27			SPEED	—

■ DIRECT MENU

No	Button	Operation
1	R/B GAIN	OK
2	R/B PED	OK
3	PED	OK
4	GAIN	OK
5	DETAIL	OK
6	MEM SETTING	—

■ MENU

		Menu	Item	Operation
1	CAMERA OPERATION	SHUTTER	SHUTTER	OK
			SPEED	OK
2	CAMERA OPERATION	ND FILTER	ND FILTER	OK
3		FUNCTION	OPTION	—
			DEFROSTER	—
			WIPER	—
			HEATER/FAN	—
			LAMP	—
4		SETUP	CAM POWER	—
	AUTO ON		—	
	RECALL PST SPD		—	
	TALLY OUT		—	
	HOME POSITION		—	
5	RP	SETUP	FOCUS/IRIS	OK
			P/T CURV	—
			BACKLIGHT	OK
			ENABLE BUTTON	OK
			MENU CONTROL	OK
			GLOBAL AREA	OK
			IP ADDRES	OK
			SUBNETMASK	OK
			GATEWAY	OK
			MAC ADDRESS	OK
			PORT CAM1~CAM100	OK
6	PTZF DIRECTION /ADJUST	PAN	CAM1~CAM100	—
7		TILT	CAM1~CAM100	—
8		ZOOM	CAM1~CAM100	—
9		FOUCS	CAM1~CAM100	—
10		PTZ ADJ	Z MIN SPEED	—
			SPEED WITH Z	—
			LIMIT UP	—
	LIMIT DOWN		—	
	LIMIT LEF		—	
		LIMIT RIGHT	—	
11	PMEM	PM GRP1	PM GRP1 MODE	—

	GROUP/ USER BUTTON SETUP		PM GRP1 1/10~10/10	—	
			PM GRP1 ALL	—	
12			PM GRP2	PM GRP2 MODE	—
				PM GRP2 1/10~10/10	—
				PM GRP2 ALL	—
13			PM GRP3	PM GRP3 MODE	—
				PM GRP3 1/10~10/10	—
				PM GRP3 ALL	—
14			PM GRP4	PM GRP4 MODE	—
				PM GRP4 1/10~10/10	—
				PM GRP4 ALL	—
15			USER	USER1~4	—
16		CAMERA CONNECTION SETUP	CTRL TYPE	CAM1~CAM100	OK
17			AUTO IP	AUTO IP	OK
18			SWAP IP	CAM1~CAM100	OK
19	MANU IP		CAM1~CAM100	OK	
20	PORT NO		CAM1~CAM100	OK	
21	SWITCHER LINK	SETUP	SW CTL	OK	
			SW IP ADDRESS	OK	
22		FUNCTION	SWLINK	OK	
			BUSCONT	OK	
			BUS	OK	
			FASIST	OK	
			CAMSEL	OK	
			TALLY_IP	OK	
			P/T/Z CONTROL	OK	
			CAMINF	OK	
			FORMAT	OK	
			CAMNAME	OK	
			SCENE	OK	
			GAIN	OK	
			SHUTTER	OK	
		IRIS	OK		
		FILTER	OK		
		ALARM	OK		
23		INPUT	INPUT1~100	OK	
24	MISC1	TALLY	TALLY IN1~10	OK	
25		GPI OUT	CAM OUT1~10	OK	
26	SD CARD	SAVE	SAVE MODE	OK	
27		LOAD	LOAD MODE	OK	
28		INIT	INITIALIZE	OK	
29	MISC2	SYSTEM	INITIALIZE	OK	
			SYSTEM VER	OK	
			PROGRAM VER	OK	
			FPGA VER	OK	
30		ALARM	POWER	—	
			CAM1~100	OK	