

Editing Controller Setting

Model : AJ-SPD850

When using the AJ-SPD850 as the PLAYER in the editing system, perform settings of the AJ-SPD850 and the controller as shown on the next page.

Applicable to : AG-A850

AJ-A900

BVE-700

BVE-900K

BVE-910

BVE-2000

AG-A850 Setting

1. Set the SETUP MENU of AJ-SPD850 as follows.
SETUP MENU No.202 : ID SEL = DVCPRO (initial setting)
2. Set the SETUP 12 (VTR CONSTANT) of controller as follows.
No.01 : DEVICE TYPE = FFFF (Default)

AJ-A900 Setting

1. Set the SETUP MENU of AJ-SPD850 as follows.
SETUP MENU No.202 : ID SEL = DVCPRO (initial setting)
2. Set the SETUP (VTR CONSTANT) of controller as follows.
No.1 : MODE = AUTO (Default)

BVE-700 Setting

1. Set the SETUP MENU of AJ-SPD850 as follows.
SETUP MENU No.202 : ID SEL = DVCPRO (initial setting)
2. Set the VTR PORT SETUP of controller as follows.

	BLOCK-1								BLOCK-2							
	BYTE								BYTE							
	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8
AJ-SPD850 (525 mode)	F0	33	00	96	06	06	02	8A	0A	0C	00	00	00	00	FF	00
AJ-SPD850 (625 mode)	F1	33	00	7D	06	06	02	8A	0A	0B	00	00	00	00	FF	00

BVE-900K, BVE-910 Setting

1. Set the SETUP MENU of AJ-SPD850 as follows.
SETUP MENU No.202 : ID SEL = DVCPRO (initial setting)
2. Set the VTR CONSTANT of controller as follows.

	CONSTANT 1								CONSTANT 2						
	BYTE								BYTE						
	1	2	3	4	5	6	7	8	1	2	3	4	5	6	7
AJ-SPD850 (525 mode)	F0	33	00	96	06	06	02	8A	0A	0C	00	00	00	3C	FF
AJ-SPD850 (625 mode)	F1	33	00	7D	06	06	02	8A	0A	0B	00	00	00	3A	FF

BVE-2000 Setting

1. Set the SETUP MENU of AJ-SPD850 as follows.
SETUP MENU No.202 : ID SEL = DVCPRO (initial setting)
2. Set the VTR CONSTANT of controller as follows.

	DATA														
	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
AJ-SPD850 (525 mode)	F0	33	00	96	06	06	02	8A	0A	0C	00	00	00	3C	FF
AJ-SPD850 (625 mode)	F1	33	00	7D	06	06	02	8A	0A	0B	00	00	00	3A	FF